

DOORS


PORTES

PORTE

Centre opening 2 panels door operator with sill and accessories

Operateurs pour ouverture centrale 2 panneaux avec seuil et accessoires

Operatori per apertura centrale 2 ante con soglia e accessori



opening

-

ouverture

-

apertura

700

800

900

1000

1100

1200

1300


1400

50 Hz	APAD-OC57	APAD-OC58	APAD-OC59	APAD-OC5A	APAD-OC5B	APAD-OC5C	APAD-OC5D	APAD-OC5E
60 Hz	APAD-OC67	APAD-OC68	APAD-OC69	APAD-OC6A	APAD-OC6B	APAD-OC6C	APAD-OC6D	APAD-OC6E

Side opening 2 panels door operator (right) with sill and accessories

Operateurs pour ouverture laterale droite, 2 panneaux avec seuil et accessoires

Operatori per apertura telescopica destra (CS) 2 ante con soglia e accessori



opening

-

ouverture

-

apertura

700

800

900

1000

1100

1200

1300


1400

50 Hz	APAD-OD57	APAD-OD58	APAD-OD59	APAD-OD5A	APAD-OD5B	APAD-OD5C	APAD-OD5D	APAD-OD5E
60 Hz	APAD-OD67	APAD-OD68	APAD-OD69	APAD-OD6A	APAD-OD6B	APAD-OD6C	APAD-OD6D	APAD-OD6E

Side opening 2 panels door operator (left) with sill and accessories

Operateurs pour ouverture laterale gauche 2 panneaux avec seuil et accessoires

Operatori per apertura telescopica sinistra (CD) 2 ante con soglia e accessori



opening

-

ouverture

-

apertura

700

800

900

1000

1100

1200

1300

1400

50 Hz	APAD-OS57	APAD-OS58	APAD-OS59	APAD-OS5A	APAD-OS5B	APAD-OS5C	APAD-OS5D	APAD-OS5E
60 Hz	APAD-OS67	APAD-OS68	APAD-OS69	APAD-OS6A	APAD-OS6B	APAD-OS6C	APAD-OS6D	APAD-OS6E