


Lighting buttons "type E"

Boutons lumineux "type E"

Pulsanti luminosi "tipo E"




Type	Cod.	
	12V	24V
without digit	APUE-PBT22	APUE-PBT42
with digit	APUE-PBT24	APUE-PBT44
	APUE-PBT39	APUE-PBT39
STOP	APUE-PBT38	APUE-PBT38
OVERLOAD	APUE-PBT26	APUE-PBT46

Lighting buttons "type C" with led and microswitch

Boutons lumineux "type C" avec microswitch et led

Pulsanti "tipo C" con pulsanti luminosi microswitch e led




Type	Cod.	
	12V	24V
without digit	APUC-PBL22	APUC-PBL42
with digit	APUC-PBL24	APUC-PBL44
	APUC-PBL39	APUC-PBL39
STOP	APUC-PBL38	APUC-PBL38
OVERLOAD	APUC-PBL26	APUC-PBL46

Lighting buttons "type D" with led and microswitch

Boutons lumineux "type D" avec microswitch et led

Pulsanti "tipo D" con pulsanti luminosi microswitch e led



Type	Cod.	
	12V	24V
without digit	APUD-PBF22	APUD-PBF42
with digit	APUD-PBF24	APUD-PBF44
	APUD-PBF39	APUD-PBF39
STOP	APUD-PBF38	APUD-PBF38
OVERLOAD	APUD-PBF26	APUD-PBF46