



Landing push button box "type C" with lighting buttons (microswitch and led)

Boîtes d'appel d'étage "type C" avec boutons lumineux (microswitch et led)

Pulsantiera di piano "tipo C" con pulsanti luminosi (microswitch e led)



Cod. CPUC-PIC3



Cod. CPUC-PIC1

