



Landing push button box “type D” with lighting buttons (microswitch and led) (12V)

Boîtes d’appel d’étage “type D” avec boutons lumineux (microswitch et led) (12V)

Pulsantiere di piano “tipo D” con pulsanti luminosi (microswitch e led) (12V)



Cod. CPUC-PID1



Cod. CPUC-PID3

